




---

# CNARDUINO

---

MB-102 830 POINT Breadboard



# **MB-102 830 POINT BREADBOARD**


# **MB-102 830 POINT BREADBOARD**

## **1.01 INTRODUCTION**

Breadboards are one of the most fundamental pieces when learning how to build circuits. In this tutorial, you will learn a little bit about what breadboards are, why they are called breadboards, and how to use one. Once you are done you should have a basic understanding of how breadboards work and be able to build a basic circuit on a breadboard.

## **HISTORY**

If you wanted to build a circuit prior to the 1960s, chances are you would have used a technique called wire-wrap. Wire wrap is a process that involves wrapping wires around conductive posts attached to a perfboard. As you can see, the process can get rather complex very quickly. Although this method is still used today, there is something that makes prototyping much easier, breadboards!



## **WHAT'S IN A NAME?**

When you picture a breadboard in your head, you may envision a big piece of wood and a large loaf of freshly baked bread. You wouldn't be too far off either.



*Bread on a breadboard*

So why do we call this electronic “circuit builder” a breadboard? Many years ago, when electronics were big and bulky, people would grab their mom’s breadboard, a few nails or thumbtacks, and start connecting wires onto the board to give themselves a platform on which to build their circuits.



*Circuit on an “original” breadboard*

Since then, electronic components have gotten a lot smaller, and we’ve come up with better ways to connect circuits, making moms all over the world happy to have their breadboards back. However, we are stuck with the confusing name. Technically, these are still breadboards, but this discussion is going to be on modern, “solderless” breadboards.


## **1.02 WHY USE BREADBOARDS?**

An electronics breadboard (as opposed to the type on which sandwiches are made) is actually referring to a **solderless breadboard**. These are great units for making temporary circuits and prototyping, and they require absolutely no soldering.

**Prototyping** is the process of testing out an idea by creating a preliminary model from which other forms are developed or copied, and it is one of the most common uses for breadboards. If you aren't sure how a circuit will react under a given set of parameters, it's best to build a prototype and test it out.


For those new to electronics and circuits, breadboards are often the best place to start. That is the real beauty of breadboards—they can house both the simplest circuit as well as very complex circuits. As you'll see later in this tutorial, if your circuit outgrows its current breadboard, others can be attached to accommodate circuits of all sizes and complexities.

Another common use of breadboards is testing out new parts, such as Integrated circuits (ICs). When you are trying to figure out how a part works and constantly rewiring things, you don't want to have to solder your connections each time.



*A circuit built on a solderless breadboard*

## **1.03 ANATOMY OF A BREADBOARD**




### **THE MAJOR FEATURES OF A BREADBOARD**

The best way to explain how a breadboard works is to take it apart and see what's inside. Using a smaller breadboard it's easier to see just how they function.

### **TERMINAL STRIPS**

Here we have a breadboard where the adhesive backing has been removed. You can see lots of horizontal rows of metal strips on the bottom of the breadboard.



A Mini Breadboard


The tops of the metal rows have little clips that hide under the plastic holes. These clips allow you to stick a wire or the leg of a component into the exposed holes on a breadboard, which then hold it in place.



*A single strip of conductive metal removed from the above breadboard.*

Once inserted that component will be electrically connected to anything else placed in that row. This is because the metal rows are conductive and allow current to flow from any point in that strip.

Notice that there are only five clips on this strip. This is typical on almost all breadboards. Thus, you can only have up to five components connected in one particular section of the breadboard. The row has ten holes, so why can you only connect five components? You'll also notice that each horizontal row is separated by a ravine, or crevasse, in the middle of the breadboard. This ravine isolates both sides of a given row from one another, and they are not electrically connected. We'll discuss the purpose of this in just a bit, but, for now, just know that each side of a given row is disconnected from the other, leaving you with five spots for components on either side.




*An LED inserted into a breadboard. Notice how each leg of the LED is placed on either side of the ravine.*

*This prevents the connections to the LED from being shorted.*

## POWER RAILS


Now that we've seen how the connections in a breadboard are made, let's look at a larger, more typical breadboard. Aside from horizontal rows, breadboards usually have what are called power rails that run vertically along the sides.



*A medium-size breadboard with the adhesive back removed to expose the power rails.*

These power rails are metal strips that are identical to the ones that run horizontally, except they are, typically\*, all connected. When building a circuit, you tend to need power in lots of different places. The power rails give you lots of easy access to power wherever you need it in your circuit. Usually they will be labeled with a ‘+’ and a ‘-’ and have a red and blue or black stripe, to indicate the positive and negative side.

It is important to be aware that the power rails on either side are not connected, so if you want the same power source on both sides, you will need to connect the two sides with some jumper wires. Keep in mind that the markings are there just as a reference. There is no rule that says you have to plug power into the ‘+’ rail and ground into the ‘-’ rail, though it’s good practice to keep everything in order.




*Two jumper wires used to connect the power rails on both sides.*

*Always attach the ‘+’ to ‘+’ and the ‘-’ to ‘-’.*

## **DIP SUPPORT**

Earlier we mentioned the ravine that isolates the two sides of a breadboard. This ravine serves a very important purpose. Many integrated circuits, often referred to as ICs or, simply, chips, are manufactured specifically to fit onto breadboards. In order to minimize the amount of space they take up on the breadboard, they come in what is known as a Dual in-line Package, or DIP.

These DIP chips (salsa anyone?) have legs that come out of both sides and fit perfectly over that ravine. Since each leg on the IC is unique, we don’t want both sides to be connected to each other. That is where the separation in the middle of the board comes in handy. Thus, we can connect components to each side of the IC without interfering with the functionality of the leg on the opposite side.



*Two DIP ICs, the LM358 (top), a very common op-amp, and the ever-popular ATmega328 microcontroller (bottom).*

## **ROWS AND COLUMNS**


You may have noticed that many breadboards have **numbers** and **letters** marked on various rows and columns. These don't serve any purpose other than to help guide you when building your circuit. Circuits can get complicated quickly, and all it takes is one misplaced leg of a component to make the entire circuit malfunction or not work at all. If you know the row number of the connection you are trying to make, it makes it much simpler to plug a wire into that number rather than eyeballing it.

## **BINDING POSTS**

Some breadboards come on a platform that has binding posts attached to it. These posts allow you to connect all kinds of different power sources to your breadboard. We'll cover these more in the next section.

## **OTHER FEATURES**

When building your circuit, you are not confined to stay on just one breadboard. Some circuits will require a lot more space. Many breadboards have little nubbins and slots on the sides, and some even have them on the tops and bottoms. These allow you to connect multiple breadboards together to form the ultimate prototyping surface.



*Breadboard Packaging.*

Some breadboards also have an adhesive backing that allow you to stick them to many different surfaces. These can come in handy if you want to attach your breadboard to the inside on an enclosure or other project case.

## **1.04 ONLINE STORE LINK TO BUY**

- [http://www.aliexpress.com/store/product/5pcs-lot-MB-102-BreadBoard-830-Point-Solderless-Universal-test-bread-board-MB102-for-Arduino-project/1036551\\_1609789057.html](http://www.aliexpress.com/store/product/5pcs-lot-MB-102-BreadBoard-830-Point-Solderless-Universal-test-bread-board-MB102-for-Arduino-project/1036551_1609789057.html)
- [http://www.aliexpress.com/store/product/40pins-one-Row-Dupont-Color-Cable-Line-male-to-female-20cm-connector-line-for-Arduino-breadboard/1036551\\_1598276043.html](http://www.aliexpress.com/store/product/40pins-one-Row-Dupont-Color-Cable-Line-male-to-female-20cm-connector-line-for-Arduino-breadboard/1036551_1598276043.html)
- [http://www.aliexpress.com/store/product/40p-Dupont-Color-Cable-Line-male-to-male-20cm-connector-line-for-Arduino-breadboard/1036551\\_1598296003.html](http://www.aliexpress.com/store/product/40p-Dupont-Color-Cable-Line-male-to-male-20cm-connector-line-for-Arduino-breadboard/1036551_1598296003.html)
- [http://www.aliexpress.com/store/product/40p-Dupont-Line-Color-Cable-female-to-female-7-87inch-connector-line-for-Arduino-breadboard/1036551\\_1598313983.html](http://www.aliexpress.com/store/product/40p-Dupont-Line-Color-Cable-female-to-female-7-87inch-connector-line-for-Arduino-breadboard/1036551_1598313983.html)
- [http://www.aliexpress.com/store/product/MB-102-BreadBoard-830-Point-Solderless-Universal-test-bread-board-MB102-for-Arduino-project/1036551\\_1609792978.html](http://www.aliexpress.com/store/product/MB-102-BreadBoard-830-Point-Solderless-Universal-test-bread-board-MB102-for-Arduino-project/1036551_1609792978.html)
- [http://www.aliexpress.com/store/product/100pcs-20CM-5-colors-female-to-female-jumper-wire-Dupont-Cable-line-1P-to-1P/1036551\\_1622581403.html](http://www.aliexpress.com/store/product/100pcs-20CM-5-colors-female-to-female-jumper-wire-Dupont-Cable-line-1P-to-1P/1036551_1622581403.html)
- [http://www.aliexpress.com/store/product/Breadboard-Line-jumper-wire-Cable-test-line-65pcs-one-lot-for-Arduino-experiment/1036551\\_1622428234.html](http://www.aliexpress.com/store/product/Breadboard-Line-jumper-wire-Cable-test-line-65pcs-one-lot-for-Arduino-experiment/1036551_1622428234.html)

---

\*Some larger breadboards will often isolate one half of the breadboard's power rails from the other half (think top and bottom half, not the sides). This is convenient if you have two different voltages with which you need to power your circuit, such as 3.3V and 5V. However, if you're unaware whether the power rails are or aren't isolated, it can often lead to issues while building your circuit. It's always a good idea to use a multimeter to check for the absence or presence of continuity in your breadboard's power rails.